

## 13mm Turbo Stealth

- To make folding easier, crease all the dashed lines with a ballpoint pen and a straight edge
- Cut out the holes for the launch rod (LR) and motor mount with a sharp craft knife.
- Cut out the Motor Mount, cut only on the solid lines and fold on the dashed lines toward the printed side.
- Form the Motor Mount into a 3 sided tube and glue together.
- Cut out the main body.
- Fold the 3 sides of the Top away from the printed side, form them into a box shape and glue using the tab.
- Fold the triangles of the Bottom toward the printed side.
- One at a time, spread glue evenly over the back (non-printed side) of the three triangles and fold them under the Top.
- Make sure all the edges line up before the glue sets.
- Fold the tabs at the top end of the Motor Mount slightly inward and spread glue on the them.
- Slide the glued end of the Motor Mount into Bottom until it makes contact with the inside of the Top.
- Put a fillet of glue around the joint between the Motor Mount and the Bottom.
- Use Estes mini motors only.

