

Stealth Version 2.0

- Print on 110 lb cardstock or posterboard.
- Crease all the dashed lines with a ballpoint pen and a straight edge, pressing down hard.
- Cut out the holes for the Motor Mount and the Launch Rod (LR) in the Top and Bottom with a sharp craft knife.
- Cut out the Motor Mount, cut only on the solid lines and fold on the dashed lines towards the printed side of the paper.
- Form the Motor Mount into a 3 sided tube and glue together.
- Cut out the main body of the Stealth and fold on the dashed lines.
- Fold the 3 sides of the TOP away from the printed side and form into a box-like shape. Glue together using the tab.
- Fold the fins marked A, B & C on the Bottom toward the printed side of the paper.
- Spread glue evenly over the back (non-printed side) of Fin A and press it flat against the inside of the Top.
- Repeat for Fins B and C making sure the sides are flat, all the edges line up and there are not gaps.
- Fold the small tabs at the top end of the MOTOR MOUNT inward slightly and put glue on them.
- Slide the glued end of the MOTOR MOUNT into the hole in the Bottom and all the way up to the center of the TOP.
- Put a fillet of glue around the joint between the MOTOR MOUNT and the Bottom.
- To fly, slide a motor into the MOTOR MOUNT.
- Use Estes A3-4T, A10-PT, A10-0 or A10-3T motors.

All rights reserved by
Art Applewhite Rockets © 2008
www.artapplewhite.com

